



INSTALLATION INSTRUCTIONS

MAKE: GM

MODEL: Silverado HD/ Sierra HD

YEAR: 06-10

ENGINE: V8-6.6L (td) LLY/LBZ/LMM

BladeRunner Turbo Inlet Manifold 46-60039-1



Parts Included:

- Turbo Inlet Manifold

Tools Needed:

- 1/4" Socket & Driver
- 5/16" Socket & Driver
- Flat head screwdriver
- 10mm Socket & Driver
- T30 Torx Bit

CAUTION: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation.

aFe recommends professional installation on our products.

1. Disconnect batteries in vehicle before installation.
2. Remove the resonator plenum by loosening the clamp and removing the T30 Torx screw.
3. Detach the CCV hose from the stock inlet manifold and the passenger side valve cover.
4. Remove the air intake system.
5. Loosen the V-band clamp at the turbocharger inlet and remove the stock turbo inlet manifold.
6. Install the aFe turbo inlet manifold onto the turbocharger using the stock V-band clamp.
7. Install the air intake system.
8. Install the CCV hose on to the aFe turbo inlet manifold and the passenger side valve cover.
9. Install the resonator plenum.
10. Connect batteries
11. Your installation is now complete.

NOTE: Place enclosed CARB EO sticker on or near the device on a smooth/clean surface. EO identification is required to pass the smog test.