



aFe Power Engine Cover

PN: 54-32418

Important!

Please read all instruction steps before you begin installation.

Make	Model	Year	Engine
Dodge/RAM	RAM 2500/3500	2013-2018	L6-6.7L (td)

Tools Required: 1) 3/8 End Wrench or Socket.

Step 1. Remove edge trim from housing.

Step 2. Slide the 3 panel nuts over the housing edge at the punched hole locations. The threaded portion should face the filter.

Step 3. Install the cover using the supplied hex screws. Do NOT over tighten.

Your install is now complete!



advanced FLOW engineering
252 Granite Street, Corona, CA 92879
Support: 951-493-7100
www.aFePower.com