



advanced FLOW engineering Intake System Cover Instruction Manual PN: 54-32578-B

Make: Dodge/RAM	Model: 1500	Year: 2014-2018	Engine: V6-3.0L (td) EcoDiesel
Make: Dodge/RAM	Model: 1500 Classic	Year: 2019	Engine: V6-3.0L (td) EcoDiesel

Important! Please read all instruction steps before you begin installation.

Step 1. Remove trim seal from housing.

Step 2. Slide cover down on housing as shown.

Step 3. Install the provided (x3) M6 screws back in place. Your install is now complete!

