



# Silver Bullet

Throttle Body Spacer

46-35002

## INSTALLATION INSTRUCTIONS

Please verify the Parts List is complete and read all steps before you begin installation.

Year	Make	Model	SubModel	Engine	Fuel
2007-2011	Jeep	Wrangler JK		V6 3.8L	Gas

1. Loosen and remove air inlet tube from air cleaner assembly and throttle body.
2. Disconnect the wire harness on the throttle body.
3. Loosen and remove the four throttle body bolts.
4. With the new 60mm bolts and flat washers, install the aFe Silver Bullet throttle body spacer and gasket into intake manifold. (The engraved side of spacer faces the throttle body with the gasket between the spacer and the throttle body. The inset portion goes into the intake manifold.) Torque the assembly to 8 ft/lbs.
5. Reconnect the throttle body wire harness.
6. Install air inlet tube and tighten clamp.
7. Your install is now complete.

NOTE: This part has been exempt by the California Air Resources Board (C.A.R.B.) and issued an Executive Order (E.O.). If part does not come with C.A.R.B. E.O. sticker already placed on device, it is necessary to place the sticker on or near the device on a smooth, clean surface. The C.A.R.B. E.O. sticker is required to pass the smog test inspections in the state of California.

### PARTS LIST

- 1 aFe Silver Bullet Spacer
- 1 Gasket
- 4 6mm x 60mm bolts
- 4 6mm flat washers

advanced FLOW engineering, inc.  
252 Granite Street, Corona, CA 92879  
Tech Support: 951-493-7185 or Tech@afepower.com  
Main Line: 951-493-7100  
www.aFePower.com

Rev 06/12/2020 kat