



Silver Bullet®

Throttle Body Spacer

PN 46-37002

Important!

Please verify the parts list and read all instruction steps before you begin installation.
(Accord shown in photo)

Make	Model	Year	Engine	Make	Model	Year	Engine
Honda	Accord	08-17	V6-3.5L	Acura	TSX	10-14	V6-3.5L
Honda	Pilot	05-15	V6-3.5L	Acura	RL	05-08	V6-3.5L
Honda	Ridgeline	06-14	V6-3.5L	Acura	TL	07-14	V6-3.5L
Honda	Odyssey	05-16	V6-3.5L	Honda	Accord Crosstour	10-11	V6-3.5L
Honda	Crosstour	12-15	V6-3.5L				

NOTE: If you have an aftermarket air intake system, you may have to adjust or trim the intake tube for the throttle body's new position.

- Step 1.** Loosen and remove the engine cover. Disconnect the crankcase hose from the air intake tube. Loosen clamps at throttle body and air box, then remove the air intake tube.
- Step 2.** Remove the throttle body by removing the two screws and the two nuts. Remove the two studs from the intake manifold using the double nut method. (Place the two OE nuts on the studs and lock them together. Then back the studs from the intake manifold.)
- Step 3.** Insert the new *Silver Bullet* throttle body spacer and provided gasket between the throttle body and manifold as shown. The "Air-In" side should face the throttle body and the gasket should go between the throttle body and the throttle body spacer.
- Step 4.** Fasten the throttle body assembly using the (4) furnished M8 screws, lock washers, and flat washers. Tighten the screws to 15 ft/lb.

Step 5. Reinstall the intake tube. Make sure to tighten all clamps and reconnect the crankcase hose.

NOTE: This part has been exempt by the California Air Resources Board (C.A.R.B.) and issued an Executive Order (E.O.). If part does not come with C.A.R.B. E.O. sticker already placed on device, it is necessary to place the sticker on or near the device on a smooth, clean surface. The C.A.R.B. E.O. sticker is required to pass the smog test inspections in the state of California.



Step 1



Step 2



Step 3



Step 4



Step 5

Parts List

- 1 *Silver Bullet* Spacer
- 1 Gasket
- 4 M8 x 80mm screws
- 4 M8 flat washers
- 4 M8 lock washers

Your install is now complete! Make sure to retighten all bolts and clamps after 100 miles of driving.

advanced FLOW engineering

252 Granite Street, Corona, CA 92879

Support: 951-493-7100

www.aFePower.com

Last Updated:
08/10/21 JRS