



P.O. Box 1719  
Corona, CA 92878  
Support: 877-512-8111  
www.aFeFilters.com

**Air Filter Installation Instructions - Ford F250/ F350/ F450/ F550/ Excursion V8-6.0L (TD) Power Stroke**

|               |                     |               |                        |                    |  |
|---------------|---------------------|---------------|------------------------|--------------------|--|
| <b>Part #</b> | 10-10100 / 71-10100 |               | <b>Tools Required:</b> | <b>Parts List:</b> |  |
| <b>Make:</b>  | Ford                |               | Knife                  | 1 Air Filter       |  |
| <b>Model</b>  | <b>Year</b>         | <b>Engine</b> |                        |                    |  |
| F250          | '03-'06             | V8-6.0L (TD)  |                        |                    |  |
| F350          | '03-'06             | V8-6.0L (TD)  |                        |                    |  |
| F450          | '03-'06             | V8-6.0L (TD)  |                        |                    |  |
| F550          | '03-'06             | V8-6.0L (TD)  |                        |                    |  |
| Excursion     | '03-'06             | V8-6.0L (TD)  |                        |                    |  |



Remove the intake system which includes the air filter. Separate the air filter from the intake system.



With a knife or sharp blade carefully cut along the edge of the OE air filter from the side opposite seal. Discard the air filter internals.



Carefully slide the air filter into the canister as shown above. Pay close attention to the alignment of the mounting slots relative to the filter housing.



Re-assemble the air filter assembly. Verify engagement grooves are positioned as shown to ensure correct installation. Reinstall assembly back into engine.