



# Silver Bullet®

Throttle Body Spacer

PN 46-37004

## INSTALLATION INSTRUCTIONS

Please verify the parts list and read all instruction steps before you begin installation.  
For the most up-to-date and complete application list, please visit our website.

| Make  | Model | Year  | Engine  | Make  | Model     | Year  | Engine  |
|-------|-------|-------|---------|-------|-----------|-------|---------|
| Acura | TLX   | 15-20 | V6-3.5L | Honda | Ridgeline | 17-21 | V6-3.5L |
| Acura | RLX   | 14-20 | V6-3.5L | Honda | Pilot     | 16-21 | V6-3.5L |
| Acura | MDX   | 14-20 | V6-3.5L | Honda | Odyssey   | 18-21 | V6-3.5L |
| Acura | RDX   | 13-18 | V6-3.5L | Honda | Passport  | 19-20 | V6-3.5L |

**NOTE:** This throttle body spacer will work with Takeda Intake System 56-70016R/D and 56-70013R/D. Proper fitment is not guaranteed with other aftermarket air intake systems.

1. Loosen and remove the engine cover. Disconnect the crankcase hose from the air intake tube. Loosen clamps at throttle body and air box, then remove the air intake tube.
2. Remove the throttle body by removing the two screws and the two nuts. Remove the two studs from the intake manifold using the double nut method. (Place the two OE nuts on the studs and lock them together; then back the studs from the intake manifold.)
3. Insert the throttle body spacer and gasket between the throttle body and manifold as shown. The "Air-In" side should face the throttle body and the gasket should go between the throttle body and the throttle body spacer.
4. Fasten the throttle body assembly using the four furnished M8 x 80mm screws, lock washers and flat washers. Tighten screws to 15 ft/lb.
5. Reinstall the intake tube and engine cover. Make sure to tighten all clamps and reconnect the crankcase hose.

Your install is now complete! Make sure to retighten all bolts and clamps after 100 miles of driving.



Step 1



Step 2



Step 3



Step 4



Step 5

### Parts List

- 1 Silver Bullet Spacer
- 1 Gasket
- 4 M8 x 80mm screws
- 4 M8 flat washers
- 4 M8 lock washers

### Tools Needed:

- 3/8 Ratchet
- 12mm socket
- Flat head screwdriver
- Pliers

advanced FLOW engineering, inc.

252 Granite Street, Corona, CA 92879

Tech Support: [www.afepower.com/contact/tech-warranty](http://www.afepower.com/contact/tech-warranty) or 951-493-7185

Main Line: 951-493-7100

[www.aFePower.com](http://www.aFePower.com)

Revised: 08-10-2021 JRS